

IMPORTANT PRODUCT & SAFETY INSTRUCTIONS



IMPORTANT PRODUCT & SAFETY INSTRUCTIONS

Read and follow these Important Product & Safety Instructions and keep for future reference.

Failure to operate this product in accordance with all instructions could result in injury to yourself or others or damage to the product or other property.

Exercise caution when using your Quark and accessories as part of your active lifestyle.

To avoid potential injury:

- Use Quark and accessories on a body mount only in non-impact activities.
- Always avoid interference with trees or other physical objects during use.

Do not drop, disassemble, modify, crush, bend, deform, puncture, shred, microwave, incinerate, or paint Quark.

Do not insert foreign objects into any opening on Quark and accessories such as the USB port.

Do not use Quark or accessories if damaged—for example, if cracked, punctured, or in contact with liquid.

Touching internal parts could result in injury or exposure to shock and/or electrical or mechanical hazards. If your Quark or accessories break and expose internal parts, contact Noir Matter Customer Support for assistance.

Your Quark Stabilizer contains a lithium-ion battery that powers the product when it is assembled and in use. The battery provided with your Quark is not user serviceable.

Batteries inside the product need to be charged before use. Always use the correct charger and refer to the manufacturer's instructions or equipment manual for proper charging instructions.

Do not attempt to remove the battery on your Quark Stabilizer as it could lead to injury or exposure to shock. Should you notice serious overheating, smoke, or a burning smell from your Quark Stabilizer, turn it off and do not use. Contact Noir Matter Customer Support for assistance.

Do not turn on your Quark Stabilizer if it is wet. If Quark Stabilizer is already on, turn it off. Allow the product to dry thoroughly before using it again.

Battery fluid can cause serious burns to the skin and eyes. In the unlikely event that battery fluid leaks onto your skin, wash the affected area with plenty of water and seek medical advice immediately.

Exercise care when attaching your camera to Quark Stabilizer or accessories to avoid damage to the camera stabilizer which is a sensitive instrument.

For safety purposes, use only genuine Noir Matter supplied or purchased parts with Quark Stabilizer.

For approved accessories, visit **noirmatter.com**.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use Quark Stabilizer under water.
6. Clean only with dry cloth.
7. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed under water, does not operate normally, or has been dropped.



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.



Removal of the rechargeable lithium-ion battery in this product should be conducted only by a qualified professional

NOIR MATTER, INC
1810 Berkeley Street, Suite G
90401 Santa Monica